


Finger Puppet Display Assembly Instructions



Unpack and locate all parts.

1, Locate the 4 largest side panels and align the edge tabs and slots.

2, Press the top hooked tabs into the long slots in the side panels. Apply pressure and slide the tabs down to lock the side assembly together.

3, Use the 4 small screws to attach the panel assembly to the spinner base .

4, Next, attach the metal magnet panels to the sides with the (12) binding post screw and nut sets.

5, Press the header sign into the slot in the top cap. Use the wooden dowel to lock it in place. Place the Top Cap on the Spinner to complete assembly.